



Assembly and instruction manual

NC rotary indexing tables

Mechanical system documentation

Document: Assembly and instruction manual

Variant: Mechanical system documentation

Valid for: Rotary indexing tables

Type: NC

Revision R12-2011

Revisions			
Date	Revision	Chapter	Reason
15.04.2010	R04-2010	All	Created
15.12.2011	R12-2011	All	Revision

This document has been prepared by

WEISS GmbH, Siemensstrasse 17, D-74722 Buchen

Service


Tel: +49 6281 52080

service@weiss-gmbh.de

www.weiss-gmbh.de

© WEISS GmbH

All rights in this document are the copyright of WEISSGmbH. This document may not be copied or reproduced, in whole or in part, without the written permission of WEISS GmbH. This document is only intended for the user of the product described and may not be passed on to third parties, in particular competitors.



List of contents

1. Introduction	5
1.1. Definition	5
1.2. Correct use	5
1.3. Incorrect use	5
1.4. Laws / EC Directives / Norms	5
1.5. EC Declaration	6
1.6. System-dependant documentation	6
1.7. Operating manual	7
1.8. Guarantee	8
2. Safety	9
2.1. Fundamental safety instructions	9
2.2. Safety equipment for the machine	10
2.3. Residual hazards	11
3. Product description	13
3.1. Structure	13
3.2. Function	13
3.3. General technical data	14
3.4. Specific technical data	16
3.5. Control unit	26
4. Transportation	27
4.1. Safety during transportation	27
4.2. Appliances and auxiliary equipment approved for transportation	27
4.3. Transportation damage	27
4.4. Intermediate storage	28
5. Installation	29
5.1. Safety during installation	29
5.2. Installation prerequisites	30
5.3. Installation of the rotary indexing table	30
5.4. Electrical connections	35
5.5. Instructions on disposal of packaging material	35
6. Commissioning	36
6.1. Safety during commissioning	36
6.2. Initial commissioning	37
6.3. Recommissioning	37
7. Operation	38
7.1. Safety during operation	38
7.2. Rotary indexing table operation	38
7.3. Operating personnel workstations	38
8. Malfunctions	39
8.1. Safety when remedying malfunctions	39
8.2. Errors / Cause / Remedy	39
8.3. Customer Service	40
9. Maintenance	41
9.1. Safety during maintenance	41
9.2. Maintenance work	42
9.3. Inspections	42
9.4. Maintenance	43
9.5. Repair	44
10. Decommissioning / Dismantling / Disposal	46
10.1. Safety during decommissioning and dismantling	46
10.2. Decommissioning	46
10.3. Dismantling and disposal	46



11. Service and spare parts	48
11.1. Ordering spare parts	48
11.2. Spare parts list	48
12. Appendix	49
12.1. Index	49
12.2. Personal notes	50

Illustration index

Machine modules	13
Example of a type plate	14
Installation positions	15
Drive positions	16
Transporting the unpacked machine	27
Adjusting the venting screw	31
Fastening the rotary indexing table	32
Displacing the drive housing	33
Pin hole axes	34
Check tooth belt tension	43
Replacing the drive motor	44
Replacing toothed belt	45



1 Introduction

1.1 Definition

A rotary indexing table of the NC series is a free-programmable rotary indexing table.

In the following, the rotary indexing table will be referred to as "machine".

1.2 Correct use

The machine is a incomplete machine as specified in Directive 2006/42/EC, Article 1g and 2g.

The machine is designed for integration in other machines, in other incomplete machines or equipment or for connection to these.

It may only be used within the limitations defined in the order characteristics.

Commissioning is prohibited until conformity with Directive 2006/42/EC, and all other applicable directives has been determined and confirmed for the facility in which the machine is installed.

Observance of the accompanying documentation and adherence to maintenance regulations are also component parts of correct use.

1.3 Incorrect use

Any use of the machine above or beyond the directions for correct use is regarded as incorrect and prohibited.

The machine should not be subject to loads beyond its stress limitations. Possible additions to the rotary table are defined in the order characteristics and must be adhered to. Additions to the table housing are prohibited. Drilling and welding to add additional components is prohibited.

Do not operate the machine without supplemental protective devices. Integration within a suitable safety concept is the responsibility of the owner.

The machine is not suitable for use

- in wet or damp environments of any kind (water, oils, acids, steam or vapours, etc.).
- in an environment with gases or radiation.
- in potentially-explosive atmospheres.

1.4 Laws / EC Directives / Norms

The machine is designed and constructed to conform to

- applicable laws
- Directive 2006/42/EC (Machinery Directive)
- Low Voltage Directive, 2006/95/EC
- EMC Directive 2004/108/EC
- and the harmonised standards that we have cited

and meets state-of-the-art technological standards in terms of its construction.



1.5 EC Declaration

An EC Declaration as specified by Directive 2006/42/EC (Machinery Directive) is included with each machine at delivery.

The text of this EC Declaration is as follows:

WEISS GmbH

Siemensstrasse 17

D-74722 Buchen, Germany

Declaration of incorporation of partly completed machinery
in accordance with EC Machinery Directive 2006/42/EC, Annex II B

Prohibition of commissioning

We hereby declare that the machine described below with the serial number NCXXXXXX is designed to be installed in another machine, or to be combined with other machines to form a larger machine in accordance with Directive 2006/42/EC.

Commissioning is prohibited until it has been established that the machine into which the aforementioned product should be installed satisfies the provisions of the EC Machinery Directive, and that a Declaration of Conformity in accordance with EC Machinery Directive 2006/42/EC, Annex II A has been issued.

1.6 System-dependant documentation

In addition to this manual, further documents are required to ensure safe operation of this machine. The specifications stated in these documents are to be observed.

- Information brochure "Free-programmable rotary indexing tables NC-T"

For control system by WEISS-GmbH:

- Operating manual WAS.handling Windows programme



1.7 Operating manual

This operating manual is a translation of the original operating manual and is part of the scope of delivery.

We reserve the right to undertake modifications resulting from further technological development which diverge from the data and illustrations contained in this operating manual.

The operating manual and the associated valid documentation are not subject to an automatic revision service.

Information on the respective current edition can be obtained from the manufacturer.

Local regulations must be heeded.

This operating manual describes handling of the machine and contains important instructions and information to assist you in correct use of the machine.

The operating manual is designed for trained technical personnel and instructed persons. It should be kept at the location of use of the machine at all times and read, understood and applied by all persons entrusted with work on or with the machine.

Safety instructions in individual chapters should be observed.





1.7.1 Explanation of safety instructions in this manual

This manual contains instructions which you should observe for your personal safety and to avoid material damage.

Safety instructions for your personal safety are highlighted by a sign containing a warning triangle and signal word. The associated text describes the hazard involved, avoidance options and the consequences of a failure to heed the safety instruction.

General instructions or instructions relating to possible material damage are highlighted by a sign without a warning triangle.



They are, depending on the degree of risk involved, illustrated as follows:

	<i>A warning triangle with the signal word DANGER indicates an immediate hazardous situation which, if not avoided, will lead to fatalities or grievous injuries.</i>
	<i>A warning triangle with the signal word WARNING indicates an potential hazardous situation which, if not avoided, can lead to fatalities or grievous injuries.</i>
	<i>A warning triangle with the signal word CAUTION indicates an potential hazardous situation which, if not avoided, can lead to light or medium injuries.</i>
	<i>A sign with the signal word NOTICE indicates potential material damage or provides additional information which should be observed when operating the machine.</i>



1.7.2 Legend

In these manual images, symbols and abbreviations with the following meaning are used for clarity:

- 1. Marks a numbered list.
 - a) Marks the second level of a numbered list.
- Marks a list.
 - ▶ Marks the second level of a list.
-  The book symbol before a section of text indicates additional applicable documents.
-  The information symbol before a section of text marks an additional note or an important tip for use.

1.7.3 Figures

The figures used are examples. There may be differences between the illustrations and the actual delivery.

1.7.4 Index of valid pages

Pages of this operating manual including the title page: 52

1.8 Guarantee

The machine is covered by a guarantee of 24 months without shift limitations.



2 Safety

2.1 Fundamental safety instructions

2.1.1 Operator's obligation to exercise diligence

This machine conforms to state-of-the-art technological standards and ensures a maximum level of safety.

However, this level of safety can only be attained under operating conditions if all measures necessary for this have been taken. The operator's obligation to exercise diligence includes planning of these measures and the inspection of their realisation.

The operator must ensure that

- the machine is only used as intended.
- the machine is only operated in faultless, functional condition and mechanical and electrical safety devices are present.
- required personal protective clothing is provided for and used by operating, maintenance and repair personnel.
- the operating manual and all other applicable documentation is maintained at all times in legible condition and is accessible at the implementation site of the machine. Ensure that all personnel who must execute activities tasks on the machine can access the operating manual at all times.
- only adequately qualified and authorised personnel maintain and repair the machine.
- such personnel are instructed regularly in all questions concerning occupational safety and environmental protection, including the operating manual and safety instructions contained therein.
- all safety instructions and warnings affixed to the product are not removed and must remain legible.
- national accident prevention guidelines and company-internal guidelines are complied with.
- VDE regulations are complied with.
- the EMC legislation is complied with during installation.



2.2 Safety equipment for the machine

2.1.2 Requirements to be met by personnel

It is imperative that the following safety instructions be observed during all operations involving the machine. This ensures avoidance of life-threatening injuries, machine damage, other material damage and environmental damage.

Personnel must ensure that

- trainees are initially permitted to only work on the machine under the supervision of an experienced person.
- all personnel who maintain the machine read the operating manual and confirm with their signature that they have understood the operating manual.
- unauthorised persons are not in the vicinity of the machine when tasks are being performed.
- supplemental to the operating manual the operating instructions as specified in labour protection legislation and work equipment use legislation are complied with.
- the operator or supervisory personnel are informed in the event of malfunction.
- required personal protective clothing is used.

The following work described in this operating manual should only be realised by qualified personnel:

- Installation
- Commissioning
- Operating
- Maintenance

2.2 Safety equipment for the machine

The operator is responsible for ensuring that a suitable safety concept is developed and applied for the safe operation of the machine.

The operator must take all measures to protect his personnel against injury by the machine.

These include:

- Protective grid with monitored safety door
- Emergency stop circuit
- Light barriers or switch mats
- Warning indicators



2.3 Residual hazards

2.3.1 General residual hazards



Risk of injury due to absent safety equipment.

Realisation of the safety concept is the responsibility of the operator. The operator must provide for adequate safety measures (e.g. safety grid, light barriers, emergency stop circuits, covers, warning indicators, etc.).

A rotating plate can collide with the loading device, if the machine is not operated properly during loading. The inertia of workpieces and the high torque can force the rotary indexing table out of its anchoring. The owner must ensure a proper supply of workpieces. Failure to comply with this instruction can result in severe or fatal injury.

Risk of explosion during operation in a potentially-explosive environment.

Due to constraints governing the correct use of the machine, the machine is not designed for use in a potentially-explosive atmosphere. The operator must take all measures to ensure that the machine is only operated in a correct manner.

Risk of injuries through burning.

Motor and the brake can reach temperatures of up to 100 °C during operation. Prior to carrying out any work on these components, the machine must first cool down sufficiently to avoid any risk of burning through contact. Burn injuries will occur if there is contact with hot components.

Use of spare parts / attachment of supplemental devices

If spare parts are used, or if supplemental devices are attached that are not approved by the manufacturer, consequential damages can occur. Only use spare parts that are cited in our spare parts list or spare parts that we have approved. You must consult with us prior to attaching supplemental devices. Failure to comply with these instructions means that the possibility of personal injury cannot be excluded.

Danger of crushing injuries due to impermissible changes

Injuries can occur as a consequence of impermissible changes. Do not make any changes to the machine. Failure to comply with these instructions means that the possibility of personal injury cannot be excluded.

2.3.2 Residual hazards due to mechanical causes



Risk of injuries due to crushing or collision.

The rotary table on the machine rotates at a very high torque. The spring-loaded brake integrated in the servo motor is a holding brake and not an approved safety brake. The brake is not a redundant design. One should therefore never reach into the working area of the rotary table. Possible injury caused by another rotating rotary table as a result of brake failure should be prevented with suitable safety equipment.



2.3.3 Residual hazards due to electrical causes




Electric shocks can cause serious to fatal injuries.

Power and control connections can still conduct electricity even if the machine is at a standstill. Work on electrical equipment should only be performed by qualified electricians in compliance with the instructions in the operating manual for the electrical system documentation. Electrical connections for the machine should only be disconnected or plugged in when the power supply is deactivated and secured against reactivation. Touching energised components can lead to serious or fatal injuries.

A failure or malfunction of the control system can lead to injuries caused by uncontrolled system behaviour or automatic startup.

The operator must take all measures to ensure that the machine is only operated in compliance with regulations.



3 Product description

3.1 Structure

The basic rotary indexing table consists of the table housing [1], the rotary table [2] and a prestressed zero-backlash reduction gear unit [3].

A servo motor [4] provided by the customer (or a servo motor from the WEISS GmbH scope of delivery) can be premounted, depending on the order.




Abb. 1: Machine modules

3.2 Function

The machine travel profile is freely programmable. The distance from one stopping point to the next is captured by an absolute measuring system (Standard).

The servo motor is actuated by the servo amplifier in compliance with the programmed motion profile and rotates, accelerates or decelerates the rotary table on the machine. The rotary table can be operated as an anticlockwise rotating, clockwise rotating or oscillating component.

The force flows from the motor via toothed belts and a one-stage gearing mechanism directly to the drive cam.

The combination of the zero-backlash and precision of the WEISS gear unit and the rotary encoder mounted on the cam enable exact positioning of the rotary table.

The rotary table is held in its position by the holding brake integrated in the servo motor when the machine is stationary. Brake pressure is generated by springs. The brake is triggered electromagnetically and activates automatically if the motor power is switched off or in the case of a power failure.

During the rotational phase, the cam rolls (with needle bearings) follow the curved path of the drive cam.

During the locking phase, four pre-tensioned cam rolls are in contact with the drive cam.



3.3 General technical data

3.3.1 Scope of delivery

The scope of delivery of the machine depends on the order involved. Please refer to the ordering information or order characteristics for individual components.

3.3.2 Type plate

The type plate is fitted to the housing of the machine and contains the details described in the illustration.

NOTICE *The illustrated type plate is merely an example of any machine and is not identical to the actual type plate of the described product.*

A second type plate is included in the scope of delivery. This second plate can be mounted at a clearly-visible location on the machine to allow viewing of performance data if the type plate fitted by the manufacturer is concealed by any other structures.

Additional barcode serial number




Abb. 2: Example of a type plate


3.3.3 Sound level

The A-weighted emission sound pressure level do not exceed the allowable peak.

3.3.4 Electrical connections

Operating voltage	Data for electrical connections is governed by the order in question. 400...480 VAC $\pm 10\%$, 48...62Hz
Brake voltage	24 VDC $\pm 10\%$, residual ripple <10%
Power input max.	NC 150T: 3kVA NC 220T: 5kVA NC 320T: 10 kVA

The wiring diagram in the motor terminal box indicates how to make the connections for the respective operating voltage and brake voltage.



3.3 General technical data

3.3.5 Rotary encoder

Type	Rotary encoder data is governed by the motor.
Resolution	
Precision	

3.3.6 Gear characteristics

Weiss standard			
Type	Reduction (Motor to encoder)	Reduction (Encoder to output shaft)	Reduction (total)
NC150T-A	12,045	1:12	144,545 (1590/11)
NC150T-B	6,4242	1:12	77,090 (848/11)
NC220T-A	14,263	1:12	171,154 (29952/175)
NC220T-B	5,943	1:12	71,314 (2496/35)
NC320T-A	13,854	1:12	166,250 (664/4)
NC320T-B	9,421	1:12	113,050 (2261/20)

See details on type plate for special versions.

3.3.7 Ambient conditions and weight

Ambient temperature	between +10 °C and +40 °C	
Weight	NC150	25 kg
	NC220	40 kg
	NC320	120 kg

3.3.8 Installation positions

Permissible installation positions for the machine are:

- normal [1]
- vertical, belt drive right [2]
- vertical, belt drive down [3]
- overhead [4]

NOTICE The bleed screw is fitted by the manufacturer according to the ordered installation position. If the installation position according to the order specification is subsequently altered, the bleed screw has to be adjusted (see chapter 5.3.3).

An installation position must never be selected where the bleed screw is pointing down. Otherwise, gear oil will escape from the bleed aperture.

An installation position must never be selected where the housing of the toothed-belt drive is facing upwards. Otherwise, lubrication can no longer be ensured.





Abb. 3: Installation positions



3.3.9 Drive positions

Permissible drive positions for the motor are:

- lateral, inside [A]
- lateral, outside [B]
- below, inside [C]
- below, outside [D]

NOTICE These drive positions are permissible for all installation positions (see chapter 3.3.8).





Abb. 4: Drive positions

NOTICE Pivoting the gear case into the required position allows the position of the motor to also be changed later (see chapter 5.3.5).

3.4 Specific technical data




3.4.1 Table type NC 150T




	NC 150T-A	NC 150T-B
Table diameter:	150 mm	150 mm
Plate diameter max:	800 mm	800 mm
Direction of rotation:	any	any
Table revolution speed max.:	31 rpm	58 rpm
Gear ratio:	$I_{tot} 144,545$	$I_{tot} 77,091$
MTM max.:	15 kgm ²	10 kgm ²
Positional accuracy:	+/- 45" (arcsec)	+/- 45" (arcsec)
max. axial run-out of the plate:	0.01 mm (for Ø 150 mm)	0.01 mm (for Ø 150 mm)
max. Excentricity:	0,01 mm	0,01 mm
Max. plane parallelism of the table surface to the housing surface	0.03 mm (for Ø 150 mm)	0.03 mm (for Ø 150 mm)
Motor data:		
Rotation speed nominal:	4500 U/min	4500 U/min
Torque nominal:	1,0 Nm	1,0 Nm
Torque peak:	4,8 Nm	4,8 Nm
Holding torque brake:	4,0 Nm	4,0 Nm




3.4 Specific technical data


3.4.1.1 Load data for the NC 150T

Fixed centre plate					
  					
permissible pull-out torque	200 Nm	permissible down-force	3500 N	permissible tangential torque	150 Nm
permissible radial force	2500 N				

Rotating plate					
  					
permissible pull-out torque locked rotary plate	500 Nm	permissible working force acting vertically at the locked rotating plate and within the nominal diameter	5500 N	Permissible tangential moment at the locked rotating plate	Permanent: 50 Nm Peak: 150 Nm
permissible pull-out torque with locked rotary plate	6000 N				



3.4.1.2 Dimensions for the NC 150T




Technical drawing of a table top (Figure 1.10). The main view shows a rectangular plate with overall dimensions of 130 mm by 150 mm. The top edge has a width of 106 mm, and the bottom edge has a width of 70 mm. The left edge has a height of 100 mm, and the right edge has a height of 80 mm. The top edge features four holes, each with a diameter of $\varnothing 6H7$. The distance between the centers of the top two holes is 106 ± 0.02 mm. The distance between the centers of the bottom two holes is 72 mm. The distance from the top edge to the center of the top two holes is 50 ± 0.02 mm. The distance from the right edge to the center of the right two holes is 65 mm. A detail view of one of the holes is shown, indicating a thread of M10.

In the event of subsequent planned drilling work, please contact us to ascertain the permissible hole depths.

The position of the rotating plate shown in the figure corresponds to the standard position of the rotary indexing table (position at time of delivery)

Max. torsional tolerance between the rotating plate and the table housing: +/- 120".




Rotary indexing tables NC R12-2011






3.4.2 Table type NC 220T

	NC 220T-A	NC 220T-B
Table diameter:	220 mm	220 mm
Plate diameter max:	1100 mm	1100 mm
Direction of rotation:	any	any
Table revolution speed max.:	23 rpm	56 rpm
Gear ratio:	$I_{\text{tot}} 171,154$	$I_{\text{tot}} 71,314$
MTM max.:	30 kgm ²	15 kgm ²
Positional accuracy:	+/- 40" (arcsec)	+/- 40" (arcsec)
max. axial run-out of the plate:	0,01 mm (for Ø 220 mm)	0,01 mm (for Ø 220 mm)
max. Excentricity:	0,01 mm	0,01 mm
Max. plane parallelism of the table surface to the housing surface	0,03 mm (for Ø 220 mm)	0,03 mm (for Ø 220 mm)
Motor data:		
Rotation speed nominal:	4000 U/min	4000 U/min
Torque nominal:	3,7 Nm	3,7 Nm
Torque peak:	7,0 Nm	7,0 Nm
Holding torque brake:	7,0 Nm	7,0 Nm

3.4.2.1 Load data for NC 220T

Fixed centre plate					
  					
permissible pull-out torque	300 Nm	permissible down-force	5000 N	permissible tangential torque	200 Nm
permissible radial force	4000 N				

Rotating plate					
  					
permissible pull-out torque locked rotary plate	700 Nm	permissible working force acting vertically at the locked rotating plate and within the nominal diameter	7500 N	Permissible tangential moment at the locked rotating plate	Permanent: 70 Nm Peak: 200 Nm
permissible pull-out torque with locked rotary plate	8000 N				

fixed


unprocessed cast edge

Drive position below (Drive can be swivelled)

Projecting edge R240


Projecting edge R190

Projecting edge R315



3.4 Specific technical data

3.4.2.3 Hole pattern for the NC 220T



Hole pattern with assembly holes (drive position below).


In the event of subsequent planned drilling work, please contact us to ascertain the permissible hole depths.

The position of the rotating plate shown in the figure corresponds to the standard position of the rotary indexing table (position at time of delivery)


Max. torsional tolerance between the fixed central plate and the rotating plate: +/- 150".

Max. torsional tolerance between the rotating plate and the table housing: +/- 100".

3.4.2.4 Motor flange



Motor flange (View from the motor side).









3.4 Specific technical data

3.4.3 Table type NC 320T


	NC 320T-A	NC 320T-B
Table diameter:	320 mm	320 mm
Plate diameter max:	1400 mm	1400 mm
Direction of rotation:	any	any
Table revolution speed max.:	24 rpm	35 rpm
Gear ratio:	$i_{\text{tot}} 166,25$	$i_{\text{tot}} 113,05$
MTM max.:	100 kgm ²	50 kgm ²
Positional accuracy:	+/- 35" (arcsec)	+/- 35" (arcsec)
max. axial run-out of the plate:	0,01 mm (for Ø 320 mm)	0,01 mm (for Ø 320 mm)
max. Excentricity:	0,01 mm	0,01 mm
Max. plane parallelism of the table surface to the housing surface	0,03 mm (for Ø 320 mm)	0,03 mm (for Ø 320 mm)
Motor data:		
Rotation speed nominal:	4000 U/min	4000 U/min
Torque nominal:	7,0 Nm	7,0 Nm
Torque peak:	12,0 Nm	12,0 Nm
Holding torque brake:	8,0 Nm	8,0 Nm

3.4.3.1 Load data for NC 320T

Fixed centre plate					
  					
permissible pull-out torque	1800 Nm	permissible down-force	18000 N	permissible tangential torque	800 Nm
permissible radial force	10000 N				
Rotating plate					
  					
permissible pull-out torque locked rotary plate	2250 Nm	permissible working force acting vertically at the locked rotating plate and within the nominal diameter	15000 N	permissible tangential torque	Permanent: 400 Nm Peak: 800 Nm
permissible pull-out torque with locked rotary plate	15000 N				



3.4.3.2 Dimensions for the NC 320T



[illegible]

In the event of subsequent planned drilling work, please contact us to ascertain the permissible hole depths.

The position of the rotating plate shown in the figure corresponds to the standard position of the rotary indexing table (position at time of delivery)

Max. torsional tolerance between the rotating plate and the table housing: +/- 80".

Technical drawing of a mechanical part showing dimensions: $\varnothing 95,5$, $\varnothing 115$, and $M 8$.

Rotary indexing tables NC R12-2011



3.5 Control unit

To control a rotary indexing table of the NC series WEISS-GmbH offers a optimized module by using the control system W.A.S (WEISS APPLIKATION SOFTWARE).



When using this control system please observe the specifications in the control instructions "WAS.indexer".

When using a manufacturer implemented control with the indexing table the information in the control instructions "WAS Commissioning and Service Software" may be used as reference values.



4.1 Safety during transportation

4 Transportation

4.1 Safety during transportation

! WARNING

Falling or sagging loads can lead to grievous injuries. Inadequately dimensioned load bearing equipment can break. Transport vehicles not designed to support the weight of the machine may fail or topple over.

Lifting devices, conveyor vehicles (pallet trucks) and load carrying equipment should conform to regulations and be designed to support the weight of the machine including packaging. It is forbidden to stand or be present under suspended or lifted loads. A falling or toppling machine can cause grievous or fatal injuries.

- Transport tasks should only be performed in compliance with the safety instructions
- Note that projecting sharp edges can cause injuries.
- The transport path must be cordoned off and safeguarded in such a manner that unauthorised personnel cannot enter the danger zone.
- The parts must be safeguarded against tipping or falling.

4.2 Appliances and auxiliary equipment approved for transportation

Eye bolts of a suitable dimension should be used for transporting the unpacked machine. The eye bolts are screwed into the external thread of the rotating plate. The lifting slings can be attached to the eyelets of the eye bolts.



Abb. 5: Transporting the unpacked machine

4.3 Transportation damage

The delivery should be inspected for damage immediately after receipt. The contents of the delivery should be checked for damage if damage to the packaging is detected, which might also indicate damage to the contents. Details of the scope of delivery are provided in Chapter 3.3.1.

Damage detected should be immediately reported to and confirmed by the transportation company.



4.4 Intermediate storage

NOTICE *The machine must not be stored in such a way that the bleed screw is pointing down, since otherwise oil may leak out.*

The storage conditions detailed in the table should be observed if intermediate storage over a longer period of time is planned.

Climatic zone	Packaging	Storage location	Storage duration
Moderate Europe USA Canada China Russia (except tropical areas)	Packed in containers	Roofed over Protected against rain and snow Not exposed to vibrations	Max. 3 years with regular inspection of packaging
	Open	Roofed over and sealed at a constant temperature and air humidity ($5\text{ °C} < T < 60\text{ °C}$, 50% relative humidity) No sudden temperature fluctuation and controlled ventilation with filter (free of dirt and dust) No aggressive vapours and no vibrations	2 years and longer with regular inspection Check for cleanliness and machine damage during inspection Check that anticorrosion protection is unspoiled
Tropical Asia Africa Central and South America Australia New Zealand (except moderate areas)	Packed in containers With moisture absorbers and humidity indicator sealed in film Protect against insect damage and mould formation through chemical treatment	Roofed over Protected against rain Not exposed to vibrations	Max. 3 years with regular inspection of packaging
	Open	Roofed over and sealed at a constant temperature and air humidity ($5\text{ °C} < T < 60\text{ °C}$, 50% relative humidity) No sudden temperature fluctuation and controlled ventilation with filter (free of dirt and dust) No aggressive vapours and no vibrations Protected against insect damage	2 years and longer with regular inspection Check for cleanliness and machine damage during inspection Check that anticorrosion protection is unspoiled



5 Installation

5.1 Safety during installation

WARNING

Falling or sagging loads can lead to grievous injuries. Inadequately dimensioned load bearing equipment can break. Transport vehicles not designed to support the weight of the machine may fail or topple over.

Lifting devices, conveyor vehicles (pallet trucks) and load carrying equipment should conform to regulations and be designed to support the weight of the machine including packaging. It is forbidden to stand or be present under suspended or lifted loads. A falling or toppling machine can cause grievous or fatal injuries.

Injuries caused by falling loads.

Parts stacked on top of each other can slip and fall. Do not loosen any fixing elements and transportation securing devices without the express instructions of the company installation personnel. Wear personal protective clothing.

Injuries caused by incorrect installation.

Improper installation can cause consequential damage. Work should only be assigned to auxiliary personnel by the company's installation personnel. The fastening material must be adequately dimensioned so that it can withstand the stresses produced during operation. The consequence of improper installation is the possibility that operating and maintenance personnel can be injured.

Injuries caused by sharp-edged machine parts which are still uncovered and accessible.

Wear personal protective clothing.

Risk emanating from rotary table which runs on.

The gearing mechanism is not self-locking. For a vertical installation of the machine (see chapter 3.3.8) gravitational forces acting on unevenly distributed loads can cause the rotating plate to rotate while bleeding the brake, leading to severe or fatal injury. The rotating plate should be supported prior to bleeding the brake, to ensure that it does not continue to rotate subsequently.

Electric shocks can cause serious to fatal injuries.

Improperly performed maintenance tasks on the electrical equipment or contact with energised lines can cause an electrical shock with severe to fatal injuries. Work on electrical equipment should only be performed by qualified electricians and in compliance with the specifications in the operating manual for electrical systems. The supply cables must be checked to ensure that they are de-energised, prior to connection. The connection to the supply energy must be established in accordance with the information in the circuit diagrams.

Danger due to missing covers

To connect the electrical components to the power supply the covers must be removed or the junction boxed must be opened. It is possible to touch energised parts. After concluding the installation tasks the covers that have been removed must be re-mounted and junction boxes must be re-closed. Failure to comply with this safety instruction result in severe or fatal injuries.

NOTICE

Incorrectly-laid cables (e.g. where the bending radius is too small) can cause cable scorching and burning. Electronic components can be damaged by electrostatic influences.



5.2 Installation prerequisites

- Ensure that only authorised personnel are in the work area of the machine and that no one could be injured due to the installation work.
- Ensure that no components are damaged and that they are only installed in clean, functional condition. Improperly placed or improperly fastened system parts can fall or tip over.
- Ensure that all components are installed in accordance with the described arrangement.
- Ensure that specified tightening torques are observed.

5.2 Installation prerequisites



Diagrams indicating the dimensions and the fastening bore holes for the individual table types are included in the supplied information brochure "Electromechanical TC rotary indexing tables".

Check prior to installation whether the dimensions of the installation site and building conditions correspond to the necessary prerequisites and measurement specification in the drawing documents.

Particularly ensure that:

- The supporting floor is level and rigid.
- The substructure of the installation site must be statically measured to an adequate degree to ensure that it can support the operating weight of the machine.
- The drive unit remains easily accessible for maintenance work and the distance between the motor ventilation system and any other sub-assembly is at least 100 mm.
- The shaft seals are protected against wear in case of abrasive ambient conditions.

5.3 Installation of the rotary indexing table

5.3.1 Operating media / Auxiliary media / Tools

The following are required for installation of the machine:

- One set of spanners
- One torque wrench
- One set of screwdrivers
- Screw securing agent (e.g. Loctite ® 243)
- Commercially-available solvents
- Drift for fitting parallel pins
- Quality 8.8 screws

Thread	M8	M10	M12	M16	M20
Tightening torque	25 Nm	50 Nm	80 Nm	200 Nm	400 Nm



5.3 Installation of the rotary indexing table

5.3.2 Installation preparation

To switch off the machine safe the measures as follows have to be provided for the power supply of the motor:

- main switch that can be locked
- suitable emergency stop devices in accordance with EN 60204-1

BEACHT *In emergency stop operation, the power supply for the motor and the brake must be interrupted.*

It must be ensured that the drive motor is sufficiently ventilated.

The motor and brake must be accessible when carrying out servicing tasks.

Prior to installation, all components must be free of anti-corrosion agents and dirt and a commercially-available solvent should be used for this purpose.

NOTICE *Do not bring the sealing lips of the oil seals in contact with the solvent, as this could cause damage to the material.*

5.3.3 Adjusting the venting screw

NOTICE *The venting screw is factory-fitted in the ordered installation position. If the installation position is changed from the position which the machine was ordered for, the venting screw must be repositioned.*

The machine is equipped with several venting holes. Unused venting holes are closed with a plug screw. If changing the mounting position, note that the venting valve always is mounted in a venting hole in the upper part of the cast metal housing.

1. Unscrew the venting screw [1], screw a plug screw [2] into the hole and tighten.
2. Move the rotary indexing table to the desired installation position.
3. Unscrew the plug screw [3] out of the relevant venting hole.
4. Screw the venting screw [1] into the hole and tighten.




Abb. 6: Adjusting the venting screw



5.3.4 Fastening the rotary indexing table

1. Place the rotary indexing table (in compliance with the transportation regulations) at the assembly position and align it with the bore holes and pin holes [1].
2. Pre-centre both cylinder pins [2] and then drive in the first pin one third of the way.
3. Screw in fastening screws [3] and slightly tighten.
4. Drive in the second parallel pin completely, followed by the first parallel pin.
5. Tighten the fixing screws firmly in a diagonal pattern with a torque wrench.
6. Make electrical connections in accordance with the circuit diagrams.
7. Perform a trial run.




Abb. 7: Fastening the rotary indexing table



5.3 Installation of the rotary indexing table

5.3.5 Displacing the drive housing

The drive housing is fitted by the manufacturer according to the ordered drive position. The drive housing can be subsequently moved to one of the permissible drive positions (see chapter 3.3.9).

1. Remove the cover of the toothed belt box.

⚠ WARNING When removing the fastening screws of the toothed-belt boxed enclosure the drive unit could tip, resulting in crushing injuries. Before loosening the screws the drive unit must be secured to prevent tipping.

2. Remove the four fastening screws [1] of the toothed-belt boxed enclosure.
3. Swivel the drive unit round to the required drive position [2].
4. Insert the four fastening screws [1] of the toothed-belt boxed enclosure and tighten firmly in a crosswise manner.
5. Cover plate of the toothed belt box




Abb. 8: Displacing the drive housing



5.3 Installation of the rotary indexing table

5.3.6 Installation of additional components

NOTICE *Use only those holes provided.*

The holes provided should be used to install additional components. Extra holes should under no circumstances be drilled in the machine or parts welded to it.

5.3.6.1 Fitting of additional indexing plates

An additional indexing plate may only be mounted with the tolerance holes, centring holes and threads provided to ensure concentricity and the accuracy of parts.

NOTICE *At the time of delivery, the rotating plate is always in the first possible locking position.*

The pin-hole axes in the rotating plate are parallel to the toothed-belt axis.

If there is a centring collar on the fixed central part of the rotary indexing table, this must not be used for fastening an additional indexing plate.

For this reason, the central bore hole of an additional indexing plate must be chosen to be approx. 2 mm larger than the centring collar.

NOTICE *Possible blockage of the rotary table caused by penetrating dirt.*

A suitable lip seal should be installed between the rotating plate and fixed plate of the machine (or between the rotating plate and optionally-mounted fixed plate) to prevent blocking of the gear unit caused by dirt penetrating the gap (WEISS recommends a gap dimension of 1mm) caused by the mounting of additional indexing plates.

Ensure when mounting the lip seal that it does not interfere with existing hole patterns.

1. Lightly polish the centring pins on the insertion side.
2. Mount the lip seal
3. Grease the lip seal all around
4. Bring the additional indexing plate into position.
5. Attach the centring plate and knock in evenly using a small hammer.
6. Fastening the additional indexing plate.




Abb. 9: Pin hole axes



5.4 Electrical connections

5.3.6.2 Pinning the mounting plates

1. Set up the mounting plate at the installation site, in compliance with the transportation guidelines, and align it to correspond to the bores and pin holes.
2. Pre-centre both parallel pins and then drive in the first parallel pin 1/3 of its length.
3. Screw in the fixing screws and tighten slightly.
4. Drive in the second parallel pin completely, followed by the first parallel pin.
5. Tighten the fixing screws firmly in a diagonal pattern with a torque wrench.

5.3.7 Installing the safety equipment


Fitting of safety equipment and emergency stop buttons is the responsibility of the operator. The machine may not be operated without safety equipment suitable for the intended purpose.

5.4 Electrical connections

Always observe the specifications in chapter 3.5 when connecting the motor and brake and when using controls.

5.5 Instructions on disposal of packaging material

Packaging materials should be reused or disposed of correctly in compliance with national regulations.



6 Commissioning

6.1 Safety during commissioning

WARNING

Injuries emanating from unexpected activation.

Incorrectly-established connections or external influences on electrical equipment can cause unexpected activation of the machine or uncontrolled movement. Ensure that nobody is present in the hazardous zone around the machine. Activate and check all safety equipment and emergency stop circuits prior to commissioning.

- Ensure that the machine is only commissioned by qualified personnel in compliance with the safety instructions.
- Ensure that only authorised personnel are in the work area, and that no one could be injured due to the commissioning process.

The following prerequisites must be met prior to commissioning the machine:


- The machine is correctly mounted.
- The electrical equipment for the power supply of the drive motor and motor brake is available and correctly fitted.
- All cables are laid properly and correctly connected in compliance with valid electrical circuit documents.
- The required safety equipment and emergency stop circuits are available and functioning correctly.

Prior to commissioning the machine, check whether

- the drive is undamaged and not blocked.
- all connections have been correctly established.
- all tools and external parts have been removed.
- all safety covers are correctly installed.
- no other hazard sources are present.

The following should be checked during commissioning

- The drive motor should run without difficulties (no overloading, no speed fluctuations).
- no excessive noise development is detected.
 - ▶ Excessive noise development can be a sign of incorrect installation if, for example, the rotary table is subjected to tension, due to an uneven supporting floor.



6.2 Initial commissioning

After switching on the power supply at the main switch, the machine is ready for operation.

6.3 Recommissioning

⚠ WARNING ***Risk of injury emanating from an operationally unsafe machine.***
An operationally unsafe machine can cause injuries and material damage. Recommissioning should only be realised after it has been ascertained that the machine is in a functionally reliable condition and no risk emanate from it during operation.

Following a temporary shutdown, a visual inspection of the machine should be conducted prior to starting up the machine again. The following should be checked and ensured in this regard:

- No damage is present on the machine.
- No foreign objects, tools or other objects are on the machine.
- All supply units are connected and operating.
- Safety equipment is ready for operation.



7 Operation

7.1 Safety during operation



Risk of injury due to incorrect alteration of operating parameters.

Improper changes of operating parameters can cause unforeseeable system behaviour. Operating parameters should only be changed by authorised personnel. Altered operating parameters should be checked in a test. Incorrect parameters can cause consequential damage and thus injuries.

Impact and crush hazards

In the event of motor brake failure, the rotary table may continue to rotate even though the motor has stopped. Do not intervene manually unless the rotating plate is stationary. If the rotating plate is still moving, then any manual intervention may lead to impact or crush injuries.

- Operating personnel must inform themselves of the proper behaviour in the event of malfunction, before switching on the machine.
- Ensure that the machine is only operated by personnel who have been trained, instructed and authorised to do so. Such personnel must be familiar with the operating manual and follow the instructions therein.
- The machine should only be used for its intended purpose (see chapter "Intended use").
- Comply with the warnings. Do not reach into moving parts.
- No one should be in the danger zone of the machine when it is being turned on and operated.
- The operating instructions issued by the owner must be complied with.


7.2 Rotary indexing table operation

The machine is designed for integration in other machines, in other incomplete machines or equipment or for connection to these.

Safe operation and control are the responsibility of the operator.

7.3 Operating personnel workstations

The operating personnel workstations are determined by the owner of the system or product in which the machine is integrated.



8.1 Safety when remedying malfunctions

8 Malfunctions

8.1 Safety when remedying malfunctions


Injury of non-authorised personnel.

Malfunctions should only be remedied by instructed personnel provided by the operator who have been trained in and are authorised to perform these tasks. The machine should be deactivated with the main switches and secured against unintentional reactivation prior to remedy. The radius of action of moving machine parts should be secured.

8.2 Errors / Cause / Remedy

8.2.1 Faults due to mechanical causes

Error	Cause	Remedy
The rotary table does not rotate.	The toothed belt between drive motor and gear unit is torn.	Replace toothed belt (see chapter 9.5.2).
	Motor voltage is missing	Measure the voltage Check fuses Check motor protection switch
	Drive motor is defective.	Replace drive motor
	The rotary table is mechanically blocked.	Check the top and bottom of the rotating plate for mechanical blockage. Remove the reason for the blockage.
		Check the gap between the fixed and rotating plate for foreign objects. Remove any foreign objects.
	There is dirt between the additional rotating plate and the fixed central plate or tension disc.	Take off rotating plate and central plate, clean them and then perform a test run without them attached.
	Initial commissioning: The rotary table is under mechanical tension.	Check that the location site is level and the machine correctly installed. Check the machine structure.



Faults or malfunctions that are caused by the control unit can be localised and eliminated in accordance with the information in the control unit documentation.



8.3 Customer Service

Please provide the following details if you require the assistance of our Customer Service:


- Serial number of the machine
- Description of the malfunction that has occurred
- Time and attendant circumstances of the malfunction that has occurred
- Assumed cause

You can contact our Customer Service from Monday to Friday between 08:00 and 17:00 at the

Service number +49 (0) 6281 - 5208-0

or at service@weiss-gmbh.de

An answering machine will provide you with information outside of the abovementioned hours.



9 Maintenance

9.1 Safety during maintenance

WARNING

Injuries caused by the power supply and residual energy.

When opening junction boxes or when removing covers live terminals and cables are accessible. All power sources must be deactivated prior to performing maintenance tasks, secured against unintentional reactivation and marked with a sign indicating that maintenance work is in progress. Work on electrical systems or equipment should only be performed by a qualified electrician or instructed personnel under the guidance and supervision of a qualified electrician according to the principles of electrical engineering. The trade-specific safety regulations must be complied with. Do not touch any open cable ends. All components with electric power supplies must be de-energized. Touching energised components can lead to serious or fatal injuries.

Risk emanating from rotary table which runs on.

The gearing mechanism is not self-locking. For a vertical installation of the machine (see Ch. 3.3.8 gravitational forces acting on unevenly distributed loads can cause the rotating plate to rotate while bleeding the brake or while moving the partition between the drive and the rotating plate. The rotating plate should be supported prior to bleeding the brake or removing the partition between the drive and the rotating plate, to ensure that it does not continue to rotate subsequently. Failure to comply with this instruction can result in severe or fatal injury.

Injury of non-authorized personnel.

Maintenance work should only be realised by instructed personnel who have been authorised to perform these tasks. The operating instructions laid down by the operator must be rigidly adhered to.

Injuries resulting from maintenance work which has not been announced.

The working area should be secured over a wide area prior to realising maintenance work and marked with warning signs. Operating personnel must be informed that maintenance work is being carried out.


Injuries caused by the use of incorrect components or incorrect operating media.

Exceeding the permissible limit values can cause damage or failure of the zero-play precision gearing mechanism. The drive unit must conform with the approved specifications regarding torque, speed and brake torque. Only spare parts included in our spare parts lists are to be used. Subsequent modifications to the rotary indexing table are not permitted. Only the specified process materials are to be used. Self-locking screws and nuts are to be continually replaced. All specified screw tightening torques are to strictly observed.

Injuries caused by the absence of safety equipment.

No safety equipment or safety components should be removed. Where dismantling of individual safety equipment is unavoidable for maintenance purposes, the parts removed should be refitted immediately after maintenance work is completed and tested to ensure that the integrity of their safety functions is assured.

- Ensure that only qualified electricians perform all tasks on the electrical equipment.
- Ensure that all work steps for maintenance are performed in the specified sequence.
- Ensure that specified tightening torques are observed.
- Ensure that all foreign objects are removed from the work area after the maintenance.



9.2 Maintenance work

Maintenance includes tasks for the purpose of:

- Inspection
- Maintenance
- Repair

⚠ WARNING *Risk emanating from unexpected activation.*

There is a risk of unexpected start-up if the power supply has not been deactivated or is inadvertent reactivated. The power supply to the machine has to be deactivated and secured against reactivation, prior to commencing maintenance work. Unexpected start up can cause severe injuries.

Impermissible changes and the use of spare parts and supplemental devices that are not approved by the manufacturer can cause injuries.

⚠ CAUTION *Burns*

Motor and the brake can reach temperatures of up to 100 °C during operation. Prior to carrying out any work on these components, the machine must first cool down sufficiently to avoid any risk of burning through contact. Burn injuries will occur if there is contact with hot components.

9.3 Inspections


9.3.1 Checking the drive motor annually

NOTICE *Replace damaged drive motor.*

Do not carry out any repairs to the drive motor independently. The drive motor has to be replaced if it is damaged (see chapter 9.5.1).

The drive motor has to be checked for

- firm seat,
- running noise and
- fouling and damage.



9.3.2 Check the toothed belt every 2 million switching operations

1. Remove the cover of the toothed belt box.
2. Visually inspect the toothed belt for mechanical damage, crack formation, and to determine whether teeth have been sheared off. A damaged toothed belt must be replaced.
3. Check tooth belt tension.

NOTICE The toothed belt is correctly tensioned if - depending on the belt length - it can easily be turned by 45° to 90° at the middle.

4. Adjust belt tension if required (see chapter 9.5.2).




Abb. 10: Check tooth belt tension

5. Cover plate of the toothed belt box

9.4 Maintenance

The machine requires no maintenance. The gears run in an oil sump, thus ensuring they are lubricated for their entire service lives.

Utilised oil:	Shell Omala 680 (CLP 680 conforming to DIN 51517)	
Oil volume:	NC 150T	0,13 l
	NC 220T	0,30 l
	NC 320T	1,50 l



9.5 Repair

9.5.1 Replacing the drive motor

Risk emanating from rotary table which runs on.

The gearing mechanism is not self-locking. For a vertical installation of the machine (see Ch. 3.3.8 gravitational forces acting on unevenly distributed loads can cause the rotating plate to rotate while bleeding the brake or while moving the partition between the drive and the rotating plate. The rotating plate should be supported prior to bleeding the brake or removing the partition between the drive and the rotating plate, to ensure that it does not continue to rotate subsequently. Failure to comply with this instruction can result in severe or fatal injury.

1. Disconnect the motor and brake.
 2. Remove the cover of the toothed belt box.
 3. Only loosen the four fixing screws [1] for the motor flange.
 4. Slacken the toothed belt [2] by moving the motor in the slots [-], and remove.
 5. Remove the screw on the cover disc [3] and pull toothed-belt pulley [4] off the motor shaft.
 6. Unscrew the four fixing screws [1] for the motor flange and take off the motor.
 7. Place the new motor on and screw in the four fixing screws [1] for the motor flange, but do not tighten them yet.
 8. Attach the toothed-belt pulley [4] to the motor shaft and fit in place using the cover disc [3] and the screw. Tighten the screw firmly.
 9. Pull on the toothed belt [2].
 10. Tighten the toothed belt by moving the motor in the slots [+] and firmly tighten the four fastening screws [1] for the motor flange.
 11. Connect the motor and brake.
 12. Perform a trial run.
 13. Check tooth belt tension.
- NOTICE** The toothed belt is correctly tensioned if - depending on the belt length - it can easily be turned by 45° to 90° at the middle.
14. Adjust belt tension if required (see chapter 9.5.2).
 15. Cover plate of the toothed belt box





Abb. 11: Replacing the drive motor



9.5.2 Replacing the toothed belt

Risk emanating from rotary table which runs on.

The gearing mechanism is not self-locking. For a vertical installation of the machine (see Ch. 3.3.8 gravitational forces acting on unevenly distributed loads can cause the rotating plate to rotate while bleeding the brake or while moving the partition between the drive and the rotating plate. The rotating plate should be supported prior to bleeding the brake or removing the partition between the drive and the rotating plate, to ensure that it does not continue to rotate subsequently. Failure to comply with this instruction can result in severe or fatal injury.

1. Remove the cover of the toothed belt box.
2. Only loosen the four fixing screws [1] for the motor flange.
3. Slacken the toothed belt [2] by moving the motor in the slots [-], and remove.
4. Pull on new toothed belt.
5. Tighten the toothed belt by moving the motor in the slots [+] and firmly tighten the four fastening screws [1] for the motor flange.

NOTICE The toothed belt is correctly tensioned if - depending on the belt length - it can easily be turned by 45° to 90° at the middle.

6. Cover plate of the toothed belt box



Abb. 12: Replacing toothed belt



10 Decommissioning / Dismantling / Disposal

10.1 Safety during decommissioning and dismantling

! WARNING

Injury of unauthorised persons.

When dismantling and during removal transport parts can tip or fall over. Ensure that decommissioning and dismantling are only executed by personnel who have been trained, instructed and authorised for this purpose. The safety instructions for transport must also be complied with for removal transport. Failure to comply with these instructions can result in serious injuries.

- Wear personal protective clothing and protective equipment.
- When dismantling and for transport removal, the safety instructions for transport and the transport guidelines must be complied with.

10.2 Decommissioning

10.2.1 Temporary decommissioning

The machine should be deactivated for decommissioning and secured against unintentional reactivation.

Workpieces which are still present on the rotary table should be removed.

The machine should be fitted with a sign that clearly indicates that it is temporarily decommissioned.


NOTICE *For recommissioning, comply with the instructions in chapter 6.3.*

10.3 Dismantling and disposal

! WARNING ***Injuries can be caused during dismantling by falling components and by swinging or falling loads during transportation with lifting equipment***

The following points must be observed to avoid injuries and/or environmental damage during dismantling and disposal:

- Ensure that the correct tools and adequately-dimensioned load lifting equipment are used and the stationary safety of dismantled machine components is assured to avoid injuries.
- Note that emerging lubricant, solvent, preserving agents, etc. can cause cauterizing and burns if they come into direct contact with skin.



10.3 Dismantling and disposal

10.3.1 Disposal of components

NOTICE *Modules should be disposed of correctly! Incorrect disposal of modules can cause environmental damage and will be prosecuted!*

Dispose of modules in compliance with valid local regulations. Ensure that auxiliary operational media are disposed of in compliance with environmental protection regulations. Local regulations governing the correct recycling and disposal of waste should be observed.

The machine consists of:

- steel and soft cast iron (housing, shafts, gears, bearings)
- copper (servo motor and electric cables)
- plastic (electric cables)
- electronic components (servo amplifier)



11 Service and spare parts

11.1 Ordering spare parts

Please supply us with the following details when ordering spare parts:

- Serial number of the machine
- Order number of the spare part obtained from the spare parts list
- Number of spare parts required

Please send your spare parts order to

WEISS GmbH
Siemensstraße 17
D-74722 Buchen/Odw.


Tel: +49 (0) 6281 - 5208-0
Fax: +49 (0) 6281 - 5208-99
eMail: service@weiss-gmbh.de
Internet: <http://www.weiss-gmbh.de>

All our representative addresses can be obtained on our website.

11.2 Spare parts list



A spare parts list is included in the supplied documentation. The exact name and order number of the required spare part can be found in this list.



12 Appendix

12.1 Index

A	
Atmosphere, explosive	5
C	
Copyright.....	2
D	
Declaration of Conformity	6
Directive 2004/108/EC (EMC directive)	5
Directive 2006/95/EC (Low voltage directive)	5
E	
EMC legislation	9
Emergency stop circuit	10
Emission sound pressure, A-weighted	14
G	
Gases or radiation	5
O	
Operating instructions.....	10
Operator's obligation	9
P	
Personnel, authorised	9
Protective clothing	29
Protective clothing, personal.....	9, 10
R	
Revisions	2
S	
Safety concept	10
Safety instructions	7, 9, 10, 36
Standards, harmonised.....	5
State-of-the-art	5
V	
VDE regulations	9
W	
WAS.handling Windows programme	6



12.2 Personal notes

[illegible]



12.2 Personal notes

Area for personal notes, consisting of multiple horizontal dashed lines for writing.



Weiss GmbH | Siemensstraße 17 | D-74722 Buchen
Telefon +49(0)6281-5208-0 | Fax +49(0)6281-520899 | info@weiss-gmbh.de | www.weiss-gmbh.de